MediaInfo源代码分析 3: Open()函数

2013年10月08日 20:27:26 阅读数:5435

MediaInfo源代码分析系列文章列表:

MediaInfo源代码分析 1:整体结构
MediaInfo源代码分析 2:API函数
MediaInfo源代码分析 3:Open()函数
MediaInfo源代码分析 4:Inform()函数
MediaInfo源代码分析 5:JPEG解析代码分析

我们来看一下MediaInfo中的Open()函数的内部调用过程

首先open函数封装了MediaInfo_Internal类中的open()函数

```
1. //打开文件
2. size_t MediaInfo::Open(const String &File_Name_)
3. {
    //封装了一层
5. return Internal->Open(File_Name_);
6. }
```

查看一下MediaInfo_Internal类中的open()函数的源代码:

```
[cpp] 📳 📑
                   //打开文件
  2.
                   size_t MediaInfo_Internal::Open(const String &File_Name_)
  3.
                   {
  4.
  5.
  6.
                                \label{lem:mediainfo_debug} $$ MEDIAINFO_DEBUG_CONFIG_TEXT(Debug+=\_T("Open, File="); Debug+=Ztring(File_Name_).c_str();) $$ A substitution of the context 
  7.
                   //清空文件列表
  8.
                                             Config.File Names.clear();
  9.
                   if (Config.File_FileNameFormat_Get()==__T("CSV"))
10.
11.
12.
                                            Config.File_Names.Separator_Set(0, __T(","));
13.
                                             Config.File_Names.Write(File_Name_);
14.
15.
                                 //添加文件名到文件名列表
16.
                   else if (!File_Name_.empty())
17.
                                             Config.File_Names.push_back(File_Name_);
18.
                   if (Config.File_Names.empty())
19.
                                {
20.
                                             CS.Leave();
21.
                                             return 0;
22.
23.
                                Config.File Names Pos=1;
                   CS.Leave();
24.
25.
                   //Parsing
26.
27.
                                 //解析
                   if (BlockMethod==1)
28.
29.
30.
                                            if (!IsInThread) //If already created, the routine will read the new files
31.
32.
33.
                                                          IsInThread=true;
34.
35.
                                             return 0;
36.
37.
                                else
                   {
38.
                                             Entry(); //Normal parsing
39.
40.
                                            return Count_Get(Stream_General);
41.
                                }
42.
              }
```

```
[cpp] 📳 📑
      //解析函数
 1.
      void MediaInfo Internal::Entry()
2.
3.
          CS.Enter():
4.
           MEDIAINFO_DEBUG_CONFIG_TEXT(Debug+=__T("Entry");)
5.
 6.
          Config.State Set(0);
7.
           CS.Leave();
8.
          //解析文件名(是否包含MMS?)
9.
           //需要libmms
10.
          if ((Config.File_Names[0].size()>=6
               && Config.File_Names[0][0]==__T('m')
11.
               && Config.File_Names[0][1]==__T('m')
12.
13.
               && Config.File Names[0][2]== T('s')
14.
              && Config.File_Names[0][3]==__T(':')
               && Config.File_Names[0][4]==_T('/')
15.
              && Config.File Names[0][5]== T('/'))
16.
               | | (Config.File Names[0].size()>=7
17.
               && Config.File Names[0][0]== T('m')
18.
19.
               && Config.File Names[0][1]== T('m')
20.
              && Config.File_Names[0][2]==__T('s')
21.
               && Config.File Names[0][3]== T('h')
22.
               && Config.File_Names[0][4]==_T(':')
23.
               && Config.File_Names[0][5]==_T('/')
24.
               && Config.File_Names[0][6]==__T('/'))
25.
               #if defined(MEDIAINFO_LIBMMS_YES)
26.
                   Reader_libmms().Format_Test(this, Config.File_Names[0])
27.
               #else //MEDIAINFO LIBMMS YES
28.
                 {
29.
                   #if MEDIAINFO EVENTS
30.
                       struct MediaInfo Event Log 0 Event;
                       Event.EventCode=MediaInfo EventCode Create(MediaInfo Parser None, MediaInfo Event Log, 0);
31.
32.
                       Event.Type=0xC0;
33.
                       Event.Severitv=0xFF:
34.
                       Event.MessageCode=0;
                       Event.MessageStringU=L"Libmms cupport is disabled due to compilation options";
35.
                       {\bf Event. Message String A="Libmms\ cupport\ is\ disabled\ due\ to\ compilation\ options";}
36
37.
                       \label{lem:mediaInfoLib::Config.Event_Send((const\ int8u^*)\&Event,\ sizeof(MediaInfo_Event\_Log\_\theta));
38.
                   #endif //MEDIAINFO EVENTS
39.
40.
               #endif //MEDIAINFO LIBMMS YES
41.
           //是否包含网络协议?(标记为://)
          //需要使用libcurl - the multiprotocol file transfer library
42.
43.
           else if (Config.File_Names[0].find(__T("://"))!=string::npos)
44.
              #if defined(MEDIAINFO LIBCURL YES)
45.
               {
46.
                   CS.Enter();
47.
                   if (Reader)
48.
49.
                       (S.Leave():
50.
                       return; //There is a problem
51.
52.
                   Reader=new Reader_libcurl();
53.
                   CS.Leave();
54.
55.
                   Reader->Format_Test(this, Config.File_Names[0]);
56.
57.
                   #if MEDIAINFO NEXTPACKET
58.
                     if (Config.NextPacket_Get())
                            return;
59.
                   #endif //MEDIAINFO NEXTPACKET
60.
61.
               #else //MEDIAINFO LIBCURL YES
62.
63.
                   #if MEDIATNEO EVENTS
64
65.
                       struct MediaInfo Event Log 0 Event;
66
                       \label{lem:event_code} Event. EventCode = MediaInfo\_EventCode\_Create(MediaInfo\_Parser\_None, \ MediaInfo\_Event\_Log, \ \theta) \ ;
67.
                       Event.Type=0xC0;
68.
                       Event.Severity=0xFF;
                       Event.MessageCode=0;
69.
70.
                       Event.MessageStringU=L"Libcurl support is disabled due to compilation options";
71.
                       Event.MessageStringA="Libcurl support is disabled due to compilation options";
                       MediaInfoLib::Config.Event_Send((const int8u*)&Event, sizeof(MediaInfo_Event_Log_0));
72.
73.
                   #endif //MEDIAINFO EVENTS
74.
               #endif //MEDIAINFO LIBCURL YES
75.
76.
           #if defined(MEDIAINFO DIRECTORY YES)
77.
               else if (Dir::Exists(Config.File Names[0]))
78.
79.
                   Reader_Directory().Format_Test(this, Config.File_Names[0]);
80.
          #endif //MEDIAINFO DIRECTORY YES
81.
           //是普诵文件,并日文件存在
82.
           #if defined(MEDIAINFO_FILE_YES)
83.
               else if (File::Exists(Config.File Names[0]))
84.
85.
                   #if defined(MEDIAINFO_REFERENCES_YES)
86.
                       string Dxw;
87.
                       if (Config.File CheckSideCarFiles Get() && !Config.File IsReferenced Get())
```

```
//Zenlib中竟然包含专用于文件名操作的类!
  89.
  90.
                                                         FileName Test(Config.File Names[0]);
                                                          //获得小写的文件名后缀
  91.
  92
                                                         Ztring FileExtension=Test.Extension_Get();
  93.
                                                          FileExtension.MakeLowerCase():
  94.
                                                         //逐个比较(这些都是文本文件的后缀)
  95.
                                                          if (FileExtension!= T("dfxp"))
  96
  97.
                                                                  Test.Extension Set( T("dfxp")):
  98.
                                                                 if (File::Exists(Test))
  99.
                                                                         Dxw+=" <clip file=\""+Test.Name_Get().To_UTF8()+".dfxp\" />\r\n";
100.
                                                          if (FileExtension!= T("sami"))
101.
102.
                                                          {
103.
                                                                  Test.Extension Set( T("sami")):
104.
                                                                 if (File::Exists(Test))
105
                                                                         Dxw+=" <clip file=\""+Test.Name Get().To UTF8()+".sami\" />\r\n";
106.
107
                                                          if (FileExtension!=__T("sc2"))
108
109
                                                                  Test.Extension Set( T("sc2"));
110.
                                                                  if (File::Exists(Test))
111.
                                                                         Dxw+=" <clip file=\""+Test.Name_Get().To_UTF8()+".sc2\" />\r\n";
112.
                                                          if (FileExtension!=__T("scc"))
113.
114.
                                                         {
                                                                  Test.Extension Set( T("scc")):
115.
116.
                                                                 if (File::Exists(Test))
                                                                         Dxw+=" <clip file=\""+Test.Name Get().To UTF8()+".scc\" />\r\n";
117.
118.
119.
                                                          if (FileExtension!=__T("smi"))
120
121.
                                                                  Test.Extension Set( T("smi"));
122
                                                                 if (File::Exists(Test))
123.
                                                                         Dxw+=" <clip file=\""+Test.Name_Get().To_UTF8()+".smi\" />\r\n";
124
                                                          //字幕
125.
126
                                                         if (FileExtension!= T("srt"))
127.
                                                          {
128.
                                                                  Test.Extension Set( T("srt"));
129.
                                                                  if (File::Exists(Test))
                                                                         Dxw+=" <clip file=\""+Test.Name Get().To UTF8()+".srt\" />\r\n
130.
131.
132.
                                                         if (FileExtension!= T("stl"))
133.
                                                          {
134
                                                                 Test.Extension Set( T("stl")):
135
                                                                  if (File::Exists(Test))
136.
                                                                         Dxw+=" <clip file=\""+Test.Name_Get().To_UTF8()+".stl\" />\r\n";
137
138
139
                                                          Ztring Name=Test.Name Get();
140.
                                                         Ztring BaseName=Name.SubString(Ztring(), __T("_"));
141.
                                                          if (!BaseName.empty())
142.
143.
                                                                  ZtringList List;
                                                                 List+=Dir::GetAllFileNames(Test.Path Get()+PathSeparator+BaseName+ T(" * audio.mp4"). Dir::Include Files):
144.
                                                                 List+=Dir::GetAllFileNames(Test.Path_Get()+PathSeparator+BaseName+__T("_*_sub.dfxp"), Dir::Include_Files);
List+=Dir::GetAllFileNames(Test.Path_Get()+PathSeparator+BaseName+__T("_*_sub.sami"), Dir::Include_Files);
145.
146.
                                                                  List+=Dir::GetAllFileNames(Test.Path_Get()+PathSeparator+BaseName+__T("_*_sub.sc2"), Dir::Include_Files);
147.
                                                                 List+=Dir::GetAllFileNames(Test.Path_Get()+PathSeparator+BaseName+__T("_*_sub.scc"), Dir::Include_Files);
148
                                                                 List+=Dir::GetAllFileNames(Test.Path_Get()+PathSeparator+BaseName+__T("_*_sub.smi"), Dir::Include_Files);
List+=Dir::GetAllFileNames(Test.Path_Get()+PathSeparator+BaseName+__T("_*_sub.srt"), Dir::Include_Files);
149.
150.
                                                                  List+=Dir::GetAllFileNames(Test.Path_Get()+PathSeparator+BaseName+__T("__*sub.stl"), Dir::Include_Files);
151
                                                                 List+=Dir::GetAllFileNames(Test.Path_Get()+PathSeparator+BaseName+__T("_*_forcesub.dfxp"), Dir::Include_File
152
                s);
153
                                                                  List+=Dir::GetAllFileNames(Test.Path Get()+PathSeparator+BaseName+ T(" * forcesub.sami"), Dir::Include File
                s);
154.
                                                                 List + = Dir:: GetAllFileNames (Test.Path\_Get() + PathSeparator + BaseName + \__T("\_*\_forcesub.sc2"), \ Dir::Include\_Files + Dir::GetAllFileNames (Test.Path\_Get() + Dir::Include\_Files + Dir::GetAllFileNames (Test.Path\_Get() + Dir::Include\_Files + Dir::GetAllFileNames (Test.Path\_Get() + Dir::GetAllFileNames (Test.Path\_Get() + Dir::GetAllFileNames (Test.Path\_Get() + Dir::GetAllFileNames (Test.Path\_Get() + Dir::GetAllFileNames (Test.Path\_GetAllFileNames (Test.Path\_GetAllFileNam
                );
155.
                                                                 List+=Dir::GetAllFileNames(Test.Path Get()+PathSeparator+BaseName+ T(" * forcesub.scc"), Dir::Include Files
                ):
156.
                                                                 List+=Dir::GetAllFileNames(Test.Path Get()+PathSeparator+BaseName+ T(" * forcesub.smi"), Dir::Include Files
                ):
157.
                                                                 List+=Dir::GetAllFileNames(Test.Path Get()+PathSeparator+BaseName+ T(" * forcesub.srt"), Dir::Include Files
                );
158
                                                                 List + = Dir:: GetAllFileNames (Test.Path\_Get() + PathSeparator + BaseName + \_T("\_*\_forcesub.stl"), \ Dir::Include\_Files + Dir::Inclu
                );
                                                                  List += Dir:: Get All File Names (Test. Path\_Get() + Path Separator + Base Name + \_T("\_*\_cc.dfxp"), \ Dir:: Include\_Files);
159.
                                                                 List+=Dir::GetAllFileNames(Test.Path_Get()+PathSeparator+BaseName+__T("_*_cc.sami"), Dir::Include_Files);
160.
                                                                  List+=Dir::GetAllFileNames(Test.Path_Get()+PathSeparator+BaseName+_T("_*_cc.sc2"), Dir::Include_Files);
161.
                                                                  List+=Dir::GetAllFileNames(Test.Path\_Get()+PathSeparator+BaseName+\__T("\_*\_cc.scc"), \ Dir::Include\_Files);
162.
163.
                                                                  List+=Dir::GetAllFileNames(Test.Path_Get()+PathSeparator+BaseName+__T("-*_cc.smi"), Dir::Include_Files);
                                                                  List+=Dir::GetAllFileNames(Test.Path_Get()+PathSeparator+BaseName+__T("_*_cc.srt"), Dir::Include_Files);
164.
                                                                  List+=Dir::GetAllFileNames(Test.Path Get()+PathSeparator+BaseName+ T(" * cc.stl"), Dir::Include Files);
165.
                                                                  for (size t Pos=0: Pos<List.size(): Pos++)</pre>
166.
                                                                         Dxw+=" <clip file=\""+List[Pos].To_UTF8()+"\" />\r\n";
167.
168.
169.
170
                                                         if (!Dxw.emptv())
171
```

88.

```
172.
 173
                                                                                             "<indexFile xmlns=\"urn:digimetrics-xml-wrapper\" xmlns:xsi=\"http://www.w3.org/2001/XMLSchema-insta</pre>
                  nce\" xsi:schemaLocation=\"urn:digimetrics-xml-wrapper DMSCLIP.XSD\">\r\n"
 174.
                                                                                                <clip source=\"main\" file=\""+FileName(Config.File_Names[0]).Name_Get().To_UTF8()+"."+FileName(Co</pre>
                  nfig.File Names[0]).Extension Get().To UTF8()+"\" />\r\n");
 175.
                                                                        Dxw.append("</indexFile>\r\n");
176.
                                                                        Config.File_FileNameFormat_Set(__T("Dxw"));
 177.
                                                               }
178.
                                                       //为空
 179
180.
                                                      if (Dxw.empty())
 181.
 182
                                                               CS.Enter();
 183
                                                               if (Reader)
 184.
 185.
 186.
                                                                         return; //There is a problem
 187.
 188.
                                                               Reader=new Reader File();
 189.
                                                               CS.Leave():
                                                               //测试格式
 190.
191.
                                                               Reader->Format_Test(this, Config.File_Names[0]);
 192.
 193.
                                                       el se
 194.
 195
                                                                //初始化Buffer
 196
                                                               Open\_Buffer\_Init(Dxw.size(), \ FileName(Config.File\_Names[0]).Path\_Get() + PathSeparator + FileName(Config.File\_Names[0]) + Path\_Get() + PathSeparator + FileNames[0]) + PathSepar
                  Name_Get());
 197.
                                                                Open_Buffer_Continue((const int8u*)Dxw.c_str(), Dxw.size());
 198.
                                                               Open_Buffer_Finalize();
 199.
                                              #else //defined(MEDIAINFO_REFERENCES_YES)
 200.
201.
                                                      CS.Enter();
                                                      if (Reader)
 202.
203.
                                                       {
 204.
                                                               CS.Leave():
 205.
                                                                return: //There is a problem
 206.
207.
                                                      Reader=new Reader File();
 208.
                                                      CS.Leave();
209
210.
                                                      Reader->Format_Test(this, Config.File_Names[0]);
211.
                                              #endif //defined(MEDIAINFO_REFERENCES_YES)
212.
 213.
                                              #if MEDIAINFO_NEXTPACKET
214.
                                                      if (Config.NextPacket_Get())
 215.
                                                                return;
216.
                                              #endif //MEDIAINFO NEXTPACKET
 217.
218.
                          #endif //MEDIAINFO FILE YES
 219.
220.
                          CS.Enter():
 221.
                           Config.State_Set(1);
222.
                          CS.Leave();
223.
                }
4
```

我们可以看出,MediaInfo支持流媒体协议作为输入源(例如mms),但前提是要使用相应的库(libmms,或者libcurl)。它会首先查找文件路径中有没有"://",判断是否是流媒体输入。

大多数情况下,我们使用本地文件路径作为输入源。这是我们就进入了代码中"#if defined(MEDIAINFO_FILE_YES) "部分下面的代码。具体每块代码的左右都写在代码注释中了,不再细说。最后使用 Reader_File的Format_Test()测试输入文件的格式。

看一下Reader_File的Format_Test()的源代码:

```
[cpp] 📳 📑
      //用于测试文件格式
 2.
      size_t Reader_File::Format_Test(MediaInfo_Internal* MI, String File_Name)
3.
 4.
         //std::cout<<Ztring(File_Name).To_Local().c_str()<<std::endl;</pre>
 5.
6.
      //With Parser MultipleParsing
7.
      MI->Open Buffer Init((int64u)-1, File Name);
8.
          if (Format_Test_PerParser(MI, File_Name))
9.
10.
              return 1:
11.
          return 0; //There is a problem
12.
13.
14.
     //Get the Extension
15.
          //文件后缀
16.
      Ztring Extension=FileName::Extension_Get(File_Name);
17.
          Extension.MakeLowerCase();
18.
19.
          //Search the theorical format from extension
        InfoMap &FormatList=MediaInfoLib::Config.Format_Get();
20.
21.
          InfoMap::iterator Format=FormatList.end();
22.
          if (!MI->Config.File ForceParser Get().empty())
23.
              Format=FormatList.find(MI->Config.File_ForceParser_Get());
24.
          if (Format==FormatList.end())
25.
26.
              Format=FormatList.begin():
              while (Format!=FormatList.end())
27.
28.
29.
                  const Ztring &Extensions=FormatList.Get(Format->first, InfoFormat_Extensions);
30.
                  if (Extensions.find(Extension)!=Error)
31.
32.
                      if(Extension.size()==Extensions.size())
33.
                          break; //Only one extenion in the list
                      if(Extensions.find(Extension+__T(" "))!=Error
34.
                      || Extensions.find(__T(" ")+Extension)!=Error)
35.
36.
                         break;
37.
                  ++Format;
38.
39.
              }
40.
          if (Format!=FormatList.end())
41.
42.
43.
              const Ztring &Parser=Format->second(InfoFormat_Parser);
44.
              if (MI->SelectFromExtension(Parser))
45.
46.
                  //Test the theorical format
47.
                  if (Format_Test_PerParser(MI, File_Name)>0)
48.
                  return 1;
49.
              }
50.
          //遍历所有支持格式,测试格式
51.
52.
          size_t ToReturn=MI->ListFormats(File_Name);
          return ToReturn;
53.
54.
```

可以看出,最后遍历了所有支持的格式,试图找出合适的格式。

最后我们看一下ListFormats()函数,用于找出匹配的格式。

由代码可见,遍历测试每一种支持的格式。

```
[cpp] 📳 📑
1.
     int MediaInfo_Internal::ListFormats(const String &File_Name)
2.
     {
3.
         // Multiple
     // 看看这些格式都是否支持
4.
         //从上往下遍历
5.
     //如果遇到某一格式,返回值为1,便不再进行
6.
         //否则就进行下一个,直到遍历完
7.
     #if defined(MEDIAINFO BDAV YES)
8.
             delete Info; Info=new File_MpegTs(); ((File_MpegTs*)Info)->BDAV_Size=4; if (((Reader_File*)Reader)->Format_Test_PerParser(th
9.
     is, File Name)>0) return 1;
10.
      #endif
11.
         #if defined(MEDIAINFO_BDMV_YES)
12.
             delete Info; Info=new File_Bdmv();
                                                            if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
13.
         #endif
14.
      #if defined(MEDIAINFO_CDXA_YES)
15.
            delete Info; Info=new File_Cdxa();
                                                            if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
16.
        #endif
         #if defined(MEDIAINFO DCP YES)
17.
            delete Info; Info=new File_Dcp();
                                                            if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
18.
         #endif
19.
20.
         #if defined(MEDIAINFO_DVDIF_YES)
```

```
delete Info; Info=new File DvDif();
21.
                                                               if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
      n 1;
22.
          #if defined(MEDIAINFO DVDV YES)
23.
             delete Info; Info=new File Dvdv();
                                                               if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
24.
      n 1;
25.
          #endif
      #if defined(MEDIAINFO DXW YES)
26.
27.
              delete Info; Info=new File Dxw();
                                                               if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
      n 1:
28.
         #endif
          #if defined(MEDIAINFO FLV YES)
29.
30.
             //检测
31.
              delete Info; Info=new File_Flv();
                                                               if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
32.
       #endif
33.
          #if defined(MEDIAINFO GXF YES)
34.
             delete Info; Info=new File_Gxf();
                                                               if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
      n 1;
35.
      #if defined(MEDIAINFO HLS YES)
36.
37.
              delete Info: Info=new File Hls():
                                                               if (((Reader File*)Reader)->Format Test PerParser(this. File Name)>0) retur
      n 1;
38.
         #endif
          #if defined(MEDIAINFO IBI YES)
39.
40.
             delete Info; Info=new File Ibi();
                                                                if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retu
      rn 1;
41.
          #endif
      #if defined(MEDIAINFO ISM YES)
42.
43.
              delete Info; Info=new File_Ism();
                                                               if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
44.
         #endif
          #if defined(MEDIAINFO IVF YES)
45.
             delete Info; Info=new File Ivf();
                                                               if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
46.
      n 1;
47.
          #endif
      #if defined(MEDIAINFO LXF YES)
48.
                                                               if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
              delete Info; Info=new File Lxf();
49.
      n 1:
50.
         #endif
          #if defined(MEDIAINFO MK YES)
51.
52.
             delete Info; Info=new File_Mk();
                                                               if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
      n 1;
53.
         #if defined(MEDIAINFO_MPEG4_YES)
54.
                                                               if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
55.
              delete Info; Info=new File_Mpeg4();
      n 1:
56.
57.
          #if defined(MEDIAINFO_MPEGPS_YES)
58.
             delete Info; Info=new File MpegPs();
                                                               if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
      n 1:
59.
          #endif
      #if defined(MEDIAINFO MPEGTS YES)
60.
61.
              delete Info; Info=new File MpegTs();
                                                               if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
      n 1:
62.
         #endif
63.
          #if defined(MEDIAINFO MPLI YES)
              delete Info; Info=new File Mpli();
                                                               if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
64
65
          #endif
         #if defined(MEDIAINFO_MXF YES)
66.
              delete Info; Info=new File Mxf();
                                                               if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
67.
      n 1;
68.
         #endif
          #if defined(MEDIAINFO NUT YES)
69.
             delete Info; Info=new File Nut();
70.
                                                               if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
71.
          #endif
         #if defined(MEDIAINFO_OGG YES)
72.
73.
              delete Info; Info=new File_0gg();
                                                               if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
      n 1;
       #endif
74.
          #if defined(MEDIAINFO P2 YES)
75
             delete Info; Info=new File_P2_Clip();
                                                               if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
76.
77.
      #if defined(MEDIAINFO_PMP_YES)
78.
79.
              delete Info; Info=new File_Pmp();
                                                               if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
      n 1;
80.
       #endif
          #if defined(MEDIAINFO RIFF YES)
81.
                                                               if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
             delete Info; Info=new File Riff();
82.
      n 1;
83.
          #endif
      #if defined(MEDIAINFO_RM YES)
84.
85.
              delete Info; Info=new File_Rm();
                                                               if (((Reader File*)Reader)->Format Test PerParser(this. File Name)>0) retur
86
       #endif
          #if defined(MEDIAINFO SEQUENCEINFO YES)
87.
             delete Info; Info=new File_SequenceInfo();
                                                               if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
88.
      n 1;
```

```
#enait
 89.
        #if defined(MEDIAINFO SKM YES)
 90.
 91.
               delete Info; Info=new File Skm();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
       n 1;
          #endif
 92
            #if defined(MEDIAINFO SWF YES)
 93.
               delete Info; Info=new File_Swf();
                                                                 if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
 94.
       n 1;
 95.
        #if defined(MEDIAINFO TSP YES)
 96.
               delete Info; Info=new File_MpegTs(); ((File_MpegTs*)Info)->TSP_Size=16; if (((Reader_File*)Reader)->Format_Test_PerParser(th
 97.
       is, File_Name)>0) return 1;
 98.
          #endif
            #if defined(MEDIAINFO WM YES)
 99.
100.
                                                                 if (((Reader File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
               delete Info; Info=new File Wm();
       n 1:
101.
            #endif
          #if defined(MEDIAINEO XDCAM YES)
102
103
               delete Info; Info=new File Xdcam Clip();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
       n 1:
104
            #endif
            #if defined(MEDIAINFO_DPG YES)
105.
                                                                 if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
               delete Info; Info=new File Dpg();
106
107
            #endif
108.
109.
            // Video
110.
        #if defined(MEDIAINFO AVC YES)
               delete Info; Info=new File Avc();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
111.
       n 1:
112.
           #endif
            #if defined(MEDIAINFO HEVC YES)
113.
114.
               delete Info; Info=new File_Hevc();
                                                                 if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
        n 1;
115
            #endif
116.
           #if defined(MEDIAINFO_AVSV_YES)
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
117.
               delete Info; Info=new File_AvsV();
       n 1:
118.
119.
            #if defined(MEDIAINFO_DIRAC_YES)
120.
               delete Info; Info=new File Dirac();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
       n 1;
121.
            #endif
        #if defined(MEDIAINFO FLIC YES)
122.
123.
               delete Info: Info=new File Flic():
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this. File Name)>0) retur
       n 1:
124
           #endif
125.
           #if defined(MEDIAINFO H263 YES)
126
               delete Info; Info=new File_H263();
                                                                 if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
       n 1;
127
            #endif
        #if defined(MEDIAINFO MPEG4V YES)
128.
               delete Info; Info=new File_Mpeg4v();
                                                                 if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
129
130.
           #endif
131.
           #if defined(MEDIAINFO MPEGV YES)
               delete Info; Info=new File Mpegv();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
132.
133.
            #endif
          #if defined(MEDIAINFO VC1 YES)
134.
               delete Info; Info=new File_Vc1();
135.
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this. File Name)>0) retur
136
           #endif
            #if defined(MEDIAINFO VC3 YES)
137.
138.
               delete Info; Info=new File_Vc3();
                                                                 if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
       n 1;
139
            #endif
        #if defined(MEDIAINFO_Y4M_YES)
140.
141.
               delete Info; Info=new File_Y4m();
                                                                 if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
       n 1;
142
        #endif
143.
        // Audio
144.
           #if defined(MEDIAINFO AAC YES)
145.
146
               delete Info: Info=new File Aac():
                                                                if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) return
        1;
147.
            #endif
148
        #if defined(MEDIAINFO AC3 YES)
149
               delete Info; Info=new File_Ac3();
                                                                 if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
        n 1:
150.
            #endif
151.
            #if defined(MEDIAINFO_SMPTEST0337_YES)
152.
               delete Info; Info=new File_SmpteSt0337();
                                                                 if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
153.
            #endif
          #if defined(MEDIAINFO_ALS_YES)
154.
               delete Info; Info=new File Als();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
155.
           #endif
156.
           #if defined(MEDIAINFO AMR YES)
157.
158.
               delete Info; Info=new File Amr();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
```

```
159
           #endif
          #if defined(MEDIAINFO AMV YES)
160.
161.
              delete Info; Info=new File Amv();
                                                                if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
       n 1;
162.
        #endif
           #if defined(MEDIAINFO APE YES)
163.
164.
              delete Info; Info=new File Ape();
                                                                if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
       n 1:
165.
           #endif
166.
       #if defined(MEDIAINFO AU YES)
167.
               delete Info; Info=new File_Au();
                                                                if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
168
           #endif
           #if defined(MEDIAINFO DTS YES)
169.
170.
               delete Info; Info=new File_Dts();
                                                                if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
       n 1;
171.
172.
       // Too many false-positives
173.
            #if defined(MEDIAINFO_DOLBYE_YES)
       11
       //
                delete Info; Info=new File DolbyE();
174.
                                                                  if (((Reader File*)Reader)
       >Format Test PerParser(this, File Name)>0) return 1:
175.
            #endif
       #if defined(MEDIAINFO_FLAC_YES)
176.
177.
               delete Info; Info=new File Flac();
                                                                if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
       n 1;
178.
          #endif
179.
           #if defined(MEDIAINFO IT YES)
180.
               delete Info; Info=new File_ImpulseTracker();
                                                                if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
181
       #if defined(MEDIAINFO LA YES)
182.
183.
               delete Info; Info=new File La();
                                                                if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
       n 1:
184.
          #endif
           #if defined(MEDIAINFO MIDI YES)
185.
              delete Info; Info=new File Midi();
                                                                if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
186.
       n 1;
187.
           #endif
           #if defined(MEDIAINFO_MOD YES)
188
189.
               delete Info; Info=new File_Module();
                                                                if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
       n 1:
190.
        #endif
           #if defined(MEDIAINFO_MPC_YES)
191
192.
              delete Info; Info=new File_Mpc();
                                                                if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
       n 1:
193.
194.
        #if defined(MEDIAINFO_MPCSV8_YES)
195.
               delete Info; Info=new File_MpcSv8();
                                                                if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
       n 1;
196.
        #endif
           #if defined(MEDIAINFO MPEGA YES)
197.
              delete Info; Info=new File Mpega();
                                                                if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
198.
       n 1:
199
           #endif
200.
       #if defined(MEDIAINFO RKAU YES)
201.
               delete Info; Info=new File_Rkau();
                                                                 if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retu
       rn 1;
       #endif
202
           #if defined(MEDIAINFO_TAK_YES)
203.
204.
              delete Info: Info=new File Tak():
                                                                if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
205.
           #endif
       #if defined(MEDIAINFO S3M YES)
206.
               delete Info; Info=new File ScreamTracker3();
                                                                if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
207.
       n 1;
          #endif
208.
           #if defined(MEDIAINFO_TTA YES)
209.
210.
              delete Info; Info=new File_Tta();
                                                                if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
211.
           #endif
       #if defined(MEDIAINFO_TWINVQ_YES)
212.
213.
               delete Info; Info=new File_TwinVQ();
                                                                if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
       n 1;
214.
        #endif
215.
           #if defined(MEDIAINFO_WVPK_YES)
216.
              delete Info; Info=new File_Wvpk();
                                                                if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
       n 1;
217.
           #endif
       #if defined(MEDIAINFO XM YES)
218.
219.
               delete Info; Info=new File ExtendedModule();
                                                                if (((Reader File*)Reader)->Format Test PerParser(this. File Name)>0) retur
       n 1;
220.
          #endif
221.
       // Text
222.
223.
           #if defined(MEDIAINFO N19 YES)
224.
               delete Info; Info=new File_N19();
                                                                if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
       n 1:
225.
           #endif
226.
       #if defined(MEDIAINFO_SCC_YES)
227.
               delete Info; Info=new File_Scc();
                                                                if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
```

```
228.
          #endif
           #if defined(MEDIATNEO SUBRIP YES)
229.
              delete Info; Info=new File SubRip();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
230
       n 1;
231.
            #endif
232.
           #if defined(MEDIAINFO_TTML_YES)
               delete Info; Info=new File Ttml();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
233.
234
          #endif
           #if defined(MEDIAINFO OTHERTEXT YES)
235.
236.
               delete Info; Info=new File OtherText();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
       n 1:
237.
            #endi1
238.
239.
            // Image
        #if defined(MEDIAINFO BMP YES)
240.
241.
               delete Info; Info=new File Bmp();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
       n 1:
242
           #endif
243.
           #if defined(MEDIAINFO DPX YES)
244
               delete Info; Info=new File_Dpx();
                                                                 if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
245
            #endif
           #if defined(MEDIAINFO GIF YES)
246.
               delete Info; Info=new File Gif();
247.
                                                                 if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
       n 1;
248.
           #endif
           #if defined(MEDIAINFO ICO YES)
249.
               delete Info; Info=new File Ico();
250.
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this. File Name)>0) retur
251.
            #endif
           #if defined(MEDIAINFO JPEG YES)
252.
253.
               delete Info; Info=new File Jpeg();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
       n 1;
254
           #endif
            #if defined(MEDIAINFO PCX YES)
255
256.
               delete Info; Info=new File_Pcx();
                                                                 if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
       n 1;
257.
258.
        #if defined(MEDIAINFO PNG YES)
259.
               delete Info; Info=new File Png();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
       n 1;
260.
        #endif
           #if defined(MEDIAINFO PSD YES)
261.
               delete Info; Info=new File Psd();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
262
       n 1;
263.
            #endif
           #if defined(MEDIAINFO TIFF YES)
264.
265.
               delete Info; Info=new File_Tiff();
                                                                 if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
266.
          #endif
267.
            #if defined(MEDIAINFO TGA YES)
268.
               delete Info; Info=new File Tga();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
       n 1:
269.
            #endif
270.
271.
            // Archive
272.
        #if defined(MEDIAINFO ACE YES)
               delete Info; Info=new File Ace();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
273.
       n 1:
274.
           #endif
            #if defined(MEDIAINFO 7Z YES)
275
276.
              delete Info; Info=new File_7z();
                                                                 if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
277.
            #endif
278.
           #if defined(MEDIAINFO_BZIP2_YES)
               delete Info; Info=new File Bzip2();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
279.
       n 1:
280
           #if defined(MEDIAINFO_ELF_YES)
281.
282.
               delete Info; Info=new File Elf();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
       n 1:
283.
            #endif
        #if defined(MEDIAINFO GZIP YES)
284.
               delete Info; Info=new File_Gzip();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
285.
       n 1;
286
           #endif
            #if defined(MEDIAINFO ISO9660 YES)
287
288.
               delete Info; Info=new File Iso9660();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
289.
           #if defined(MEDIAINFO MZ YES)
290.
291.
               delete Info; Info=new File Mz();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
       n 1:
292.
           #endif
            #if defined(MEDIAINFO RAR YES)
293.
               delete Info; Info=new File Rar();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
294.
       n 1;
            #endif
295.
296.
           #if defined(MEDIAINFO TAR YES)
297.
               delete Info; Info=new File Tar();
                                                                 if (((Reader File*)Reader)->Format Test PerParser(this, File Name)>0) retur
```

```
298.
299.
          #if defined(MEDIAINFO ZIP YES)
300.
             delete Info; Info=new File_Zip();
                                                             if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
       n 1;
301.
          #endif
302.
303.
          // Other
      #if !defined(MEDIAINFO_OTHER_NO)
304.
305.
              delete Info; Info=new File_Other();
                                                             if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
       n 1;
306.
       #endif
307.
308.
      // Default (empty)
309.
              delete Info; Info=new File_Unknown();
                                                             if (((Reader_File*)Reader)->Format_Test_PerParser(this, File_Name)>0) retur
      n 1;
310.
       return 0;
311. }
```

至此Open()函数的分析完毕。

版权声明:本文为博主原创文章,未经博主允许不得转载。 https://blog.csdn.net/leixiaohua1020/article/details/12449803

文章标签: (mediainfo) (open) (函数分析) (源代码) 个人分类: MediaInfo

所属专栏: 开源多媒体项目源代码分析

此PDF由spygg生成,请尊重原作者版权!!!

我的邮箱:liushidc@163.com